# AnDAPT

## Zoom Controller Power Component: 1483

## **Product Description**

The I483 Component is a customizable 1 or 2 channel PWM generator targeted at DC motor or stepper motor driving.

#### Features

- Two independent PWM channels
- Selectable pulse rates 100pps to 1000pps
- I2C controlled sequencer 1- 511 pulses
- I2C controlled Low Power mode
- I2C controlled CW / CCW direction
- Autonomous accelerate & decelerate phases

## Applications

• Stepper motor driving

Figure 1: I483 component symbol

## Pin Function and Description Table

Port Name	I/O	Description
PhaseA[4:1]	0	PWM A output phases
PhaseB[4:1]	0	PWM B output phases
EN	I	Currently no connection, possible future expansion

## Theory of operation

Each of the two independent PWM generators produces quadrature output phases. The min. and max. rate of these phases is parameterized from 100pps to 1000pps. The outputs can be set to a low power state where all phases are logic 0, exiting from low power returns the outputs to the same state as when low power was entered. An I2C controlled sequencer commands the PWM generators to accelerate from min to max rate, run for up to 2048 cycles at max rate and then decelerate from max to min rate. This sequence is autonomous and begins once the I2C transaction is complete. The accelerate and decelerate sequence can optionally be disabled and the PWM will run at the min rate for the entire sequence. The outputs can follow a P1->P2->P3->P4 or P4->P3->P2->P1 direction also under I2C control. There is an I2C register which can be read to determine if the PWM is running or stopped.

#### **Block Diagram**



### **Electrical Characteristics**

#### VIN=12V, TA=25°C unless otherwise specified

Parameter	Condition	Min	Тур	Max	Units
Pulse rate		100		1000	Hz
Pulse rate accuracy	Vin=12V, T <sub>A</sub> =25°C	-7		+7	%
	-40°C <t<sub>A&lt;150°C</t<sub>	-9		+9	%

#### **Recommended Operating Conditions**

#### over operating free-air temperature range

Symbol	Parameter	Min	Тур	Max	Unit
VIN	Input Voltage	4.5		14	V
Fout	Output pulse rate.	100		1000	Hz

#### **Parameter Settings**

#### **Basic Configuration**

Default parameters may be changed per user requirement.

─ ☑PWM Chan A →			
PWMA Min O	400	~	Hz
PWMA Max O	800	~	Hz
─ ✓PWM Chan B ─			
PWMB Min O	400	~	Hz
PWMB Max O	800	~	Hz
	100 200 300 400 500 600 700 800 900 <b>1000</b>		
Update	900 1000	Done	

1483